DOOR AND WINDOW SCHEDULE

BASEMENT

MARK	TYPE	LOCATION	WIDTH	HEIGHT	SILL
1	HINGED DOOR	BOILER ROOM	2'-4 3/4"	6'-8 1/4"	0"
A	SLIDING WINDOW	UNFINISHED BASEMENT	2'-3 3/4"	3'-11 1/4"	3'-3 1/4"
B	SLIDING WINDOW	UNFINISHED BASEMENT	2'-3 3/4"	3'-11 1/4"	3'-3 1/4"

FIRST FLOOR

MARK	TYPE	LOCATION	WIDTH	HEIGHT	SILL
1	HINGED DOOR	LIVING ROOM	2'-10"	6'-2 3/4"	0"
2	HINGED DOOR	CLOSET	2'-1 1/2"	5'-9 1/4"	6 3/4"
3	HINGED DOOR	KITCHEN	2'-7 1/2"	6'-8 1/4"	0"
4	HINGED DOOR	KITCHEN	2'-7 1/2"	6'-8 1/4"	0"
A	HUNG WINDOW	LIVING ROOM	1'-1"	5'-1 1/4"	2'-9 1/2"
B	HUNG WINDOW	LIVING ROOM	2'-11 1/4"	5'-2 3/4"	2'-9 3/4"
C	HUNG WINDOW	LIVING ROOM	1'-0"	5'-0"	2'-10 1/4"
D	HUNG WINDOW	DINING ROOM	2'-6"	5'-8 1/2"	2'-6 1/4"
E	HUNG WINDOW	DINING ROOM	2'-2 1/4"	5'-5 1/4"	2'-7 1/4"
F	HUNG WINDOW	KITCHEN	3'-7 1/4"	4'-7"	3'-8 1/2"
G	HUNG WINDOW	KITCHEN	2'-7 1/2"	3'-11 1/4"	3'-3 1/4"
H	HUNG WINDOW	KITCHEN	1'-9 1/2"	3'-7 3/4"	4'-7 3/4"

SECOND FLOOR

MARK	TYPE	LOCATION	WIDTH	HEIGHT	SILL
1	BYPASS DOOR	CLOSET (FRONT)	4'-9"	7'-1"	0"
2	HINGED DOOR	BEDROOM (FRONT)	3'-1 1/4"	7'-1 1/4"	0"
3	HINGED DOOR	CLOSET (MIDDLE)	2'-9 3/4"	7'-1"	0"
4	HINGED DOOR	BEDROOM (MIDDLE)	3'-0"	6'-3 1/4"	0"
5	HINGED DOOR	BATHROOM	2'-5"	6'-2 3/4"	0"
6	HINGED DOOR	BEDROOM (REAR)	3'-0"	7'-5 1/4"	0"
7	BYPASS DOOR	CLOSET (REAR)	4'-4"	7'-0 3/4"	0"
A	HUNG WINDOW (BAY)	BEDROOM (FRONT)	2'-10"	5'-5"	2'-3"
B	HUNG WINDOW (BAY)	BEDROOM (FRONT)	2'-3 1/4"	5'-6 1/4"	2'-2 1/2"
C	HUNG WINDOW (BAY)	BEDROOM (FRONT)	2'-5 1/4"	5'-6 1/2"	2'-2 1/4"
D	HUNG WINDOW	BEDROOM (MIDDLE)	2'-5"	5'-4 1/2"	2'-6 3/4"
E	HUNG WINDOW	BATHROOM	3'-0 3/4"	4'-10 1/2"	3'-6 1/2"
F	HUNG WINDOW	BEDROOM (REAR)	2'-6 1/4"	4'-8 1/2"	3'-2 1/4"
G	HUNG WINDOW	BEDROOM (REAR)	2'-8 1/2"	5'-4 1/4"	2'-5"

LINES & PLANS

Existing Conditions Floor Plans

Philadelphia, PA

PROJECT

Sample: Philadelphia rowhouse

3 levels: basement, first, second

SHEET TITLE

Door and Window Schedule

DRAWN / FIELD-MEASURED BY

Keith Alford

SCALE

1/4" = 1'-0" on 24x36

NOTES

1. Widths, heights and sill heights as measured in the field with the scan app. Width is the clear opening width entered for the object.
2. Sill is the distance from finished floor to the bottom of the opening. Doors with a 0 sill sit on the floor.
3. Bypass doors and cased openings have no swing shown on the plan.
4. Doors are numbered and windows lettered on each level. Marks match the plan sheet and the MARK attribute in the DXF blocks. Cased openings are not scheduled.
5. Verify all dimensions in field before construction or fabrication.
6. Not a land or boundary survey.

DATE	JOB NO.	REV
11/10/2026	SAMPLE	0

REVISION: 0, issued for portfolio.

SHEET

EX-3